

2007 Buell Ulysses XB12X Suspension Settings

TOTAL RIDER & CARGO WEIGHT		FRONT FORKS			REAR SHOCK		
LBS	KG	PRELOAD (# of lines showing)	*COMPRESSION	*REBOUND	PRELOAD (turns in from min)	*COMPRESSION	*REBOUND
*Under 170	Less than 77	6	1.25	1.75	4	2	1.75
170-200	77-91	5	1	1.625	8	1.75	1.25
200-230	91-104	5	1	1.625	12	1.5	1
230-260	104-118	4	1	1.5	16	1.25	0.875
260-290	118-132	4	0.75	1.5	20 (max)	1	0.75
290-320	132-145	3	0.75	1.25	20 (max)	0.75	0.625
320-GVWR	145-GVWR	3	0.75	1.25	20 (max)	0.5	0.5

* All damping adjustments are turns out from maximum.

** Note: The rear preload knob has a click every 1/2 turn. For example: 4 turns from minimum would be 8 clicks.
5 Turns (10 clicks) will move it one reference line.